



▶ General Information:

Kit includes; Base, bungee pole set, top rail and carry bag.

Available size/style; 800mm (Twin Foot)

▶ Unit Weight:

2.4kg approx. (including carry bag).

▶ Artwork Specifications:

Visible Area: 2000mm[†] (H) x 800mm (W)

[†] Add extra 200mm to visible length to allow for roller mechanism.

Product Name: Grasshopper

Type: Roller Banner



Economy



Roller Banner

User Instructions

- 1 Twist out both feet through 90° from base of stand.
- 2 Fit bungee pole together, and insert into base of stand.
- 3 Lean unit back slightly and while holding the top rail, extend the graphic out of the base.
- 4 Locate the plastic cap on the top rail onto the top of the pole to secure the graphic.